Service Information

Mazda Motor Corporation





+Category N	Repair Gui	Ref. No. R070/13	Page 1 of 2	
Coverage □ Distributor only ■ Please inform your dealers			Date Issued September 17, 2013	
Please convey this information to your □ Director □ General Manager Warranty Dept. □ Parts Dept. □ Training Dept. □ Field Rep.		0	Date Revised	
Applicable Model		Applicable Countries or Specifications		
CX-5 (KE)		Worldwide		


Subject: Unusual noise when vehicle is started with steering wheel fully turned to driver-seat side

DESCRIPTION

Some vehicles may exhibit an unusual noise (clacking) from under the vehicle front when the vehicle is started after the steering wheel is fully turned to the driver-seat side (left-side for LHD and right-side for RHD vehicle). The noise will not occur when the vehicle is started with the steering wheel fully turned to the passenger side.

CAUSE

An edge of the inner ball joint at the driver-seat side may get stuck with the steering gear housing, causing a stick-slip noise.



MASS PRODUCTION CHANGE

The shape of the inner ball joint edge has been changed.

US Spec.	
JM3 KE**** ** 369145	July 3, 2013
EC Spec.	•
JMZ KE**** ** 232774	July 3, 2013
ADR Spec.	
JM0 KE**** ** 214894	July 3, 2013
General Spec.	
JM6 KE**** ** 214894	July 3, 2013
JM8 KE**** ** 214894	July 3, 2013
	-

Israel Spec.	
JMZ KE**** ** 232774	July 3, 2013
Algeria Spec.	
KE**** ** 214894	July 3, 2013
China Spec.	
JM7 KE**** ** 214894	July 3, 2013

REPAIR PROCEDURE

- 1. Verify customer complaint.
 - 1 Stop the vehicle after the steering wheel is fully turned to the direction where the driver's seat is installed.
 - ② Verify that the noise occurs when starting the vehicle.
 - Note: Refer to the noise sample in the attached video file.
- 2. If the noise is reproduced, remove the steering gear and linkage from the vehicle according to the Workshop Manual "STEERING GEAR AND LINKAGE REMOVAL" and replace the inner ball joint (driver-seat side) with a modified one according to the Workshop Manual "STEERING GEAR AND LINKAGE DISASSEMBLY".
- 3. Install the steering gear and linkage in the reverse order of removal.
- 4. Verify the repair.

PART INFORMATION		

Part Number		Part Name	O'ty	Remark	
New	Old	Fait Name	Q'ty	Remark	
KD31 32 240A	KD31 32 240	Inner Ball Joint	1		
BBM4 32 127		Wire Clamp	1	Replace part See the illustration in the 1 st page for the location.	
B455 32 099B		Joint Bolt	1	Replace part (Joint bolt between intermediate shaft and steering gear & linkage assembly)	
T060 26 169A		Snap Pin	2	Replace part (Snap pins for outer ball joint (tie rod end))-both sides	

WARRANTY INFORMATION

Assembly group	N – Steering system
Subassembly group	02 – STEERING GEAR & LINKAGE
Symptom Code	82
Damage Code	9M
Causal Part No.	KD31 32 240A
Q'ty	1
Operation No.	XXJASXRX
	Inner bolt joint, R&R (driver-side)
	Includes: Front wheel alignment check and adjust
Labor Hours	2.8Hrs.
Period Covered	Normal warranty period