

Hymee RX8 Short Shifter Fitting Instructions

- 1) First, undo the shift knob. It's a standard right hand thread. Undo by twisting counter-clockwise. If you have an illuminated shift knob, take extreme care not to damage the wiring, you may wish to release the shifter cover to check on the wiring layout underneath first.
- 2) You must now remove the shifter cover. You have to gain access to the rear right hand tab of the shifter cover. Remove the small panel located forward of the cup-holders (see picture).



Hymee Tip : for those with long fingers, if you release the handbrake, you can push this handbrake adjust access panel aft by reaching through the gap at the back of the handle and lifting the tang from inside.

- 3) Now having removed the small handbrake adjust access panel, you can get to the rear right hand tab securing the shifter cover. You need to reach in and use your finger to release the tab from the console base. Take care, this one tab is very fragile!

