

NEO COMPATIBILITY GUIDE

ACURA

ALL MODELS 1992-2002

* TL 1999-2002 use Honda cable behind radio. Not compatible with NSX, SLX, and MDX 1996+. Not compatible with Acura vehicles with navigation.

AUDI

ALL MODELS 1998-2004

* All models 1998-2004 use pre-wired 13-pin cable in the left rear trunk. Not compatible with A8 2003+, and A6 2004+.

BUICK

Century 1997-2003

Le Sabre 1999-2002

Park Ave 1995-2005

Regal 1995-2003

Rendezvous 2003-2005

Riviera 1996-1999

Roadmaster 1995-1996

Skylark 1996-1998

CADILLAC

Catera 1997-1999

DeVille 1995-2005

El Dorado 1995-2002

Escalade 1999-2005

Seville 1995-2004

CHEVROLET

Astro Van 1996-2005

Avalanche 2002-2005

Blazer 1998-2002

Camaro 1997-2002

Cavalier 1996-1999

2003-2005

Corvette 1997-2004

* Some may require part # CP-140.

Equinox 2005

Impala 1995-2005

Lumina 1996-1999

Malibu 1997-2000

Monte Carlo 1995-2005

Silverado 1996-2005

Suburban 1995-2005

Tahoe 1995-2005

Trailblazer 2004-2005

Venture 1997-1999

2004-2005

CHRYSLER

ALL MODELS 1995-2004

* All models must have "Disc ^" printed on Preset Button # 1. Not compatible with 300M 2004+.

DODGE

ALL MODELS 1995-2004

* All models must have "Disc ^" printed on Preset Button # 1. Not compatible with Magnum 2004+ & Durango 2004+.

EAGLE

ALL MODELS 1995-2004

* All models must have "Disc ^" printed on Preset Button # 1.

FORD

Crown Victoria 1995-2003

Escape 2001-2004

Econoline 1997-2004

Escort 1997-2004

Excursion 2000-2004

Expedition 1997-2003

Explorer 1995-2004

Freestar 1999-2004

F-Series Pick-Up 1995-2003

Focus 2000-2003

HN80 Heavy Truck 1996-1997

Mustang 2001-2004

Ranger 1995-2004

Sport Trac 2000-2004

Taurus 1996-2004

Thunderbird 2000-2004

Windstar 1999-2004

GMC

Envoy 1999-2001

2004-2005

Denali/XL 1995-2004

Jimmy 1998-2002

Sonoma 1998-2002

Safari 1996-2005

Savana 1999-2000

Sierra 1995-2004

Suburban 1995-2002

Yukon/XL 1995-2005

HONDA

Accord 1992-2002

ALL MODELS 1992-2004

* Not compatible w/ Element 2003+, Accord 2004+, and S2000 2004+.

HUMMER

Hummer H2 2003-2005

ISUZU

Amigo 1998-2002

Rodeo 1998-2002

Trooper 1998-2002

JAGUAR

S-Type 2000-2002

JEEP

ALL MODELS 1995-2004

* All models must have "Disc ^" printed on Preset Button # 1.

LINCOLN

Aviator 2003

Continental 1995-2004

LS 2000-2003

Mark VIII 1995-1998

Navigator 1997-2003

Town Car 1995-2003

MAZDA

B Truck 1997-2001

Tribute 2001-2002

MERCURY

Cougar 1999-2004

Grand Marquis 1997-2003

Mountaineer 1997-2004

Sable 1996-2005

Tracer 1995-2004

Villager 1997-2002

NISSAN

Quest 1997-2002

OLDSMOBILE

Achieva 1996-1998

Alero 1999-2004

Aurora 1995-2004

Bravado 1997-2001, 2004

Cutlass 1997-1999

Cutlass Supreme 1995-1997

Eighty-Eight 1996-1999

Intrigue 1998-2001

LSS 1996-1999

Regency 1997-1998

Silhouette 1996-1999, 2004

PLYMOUTH

ALL MODELS 1995-2004

* All models must have "Disc ^" printed on Preset Button # 1.

PONTIAC

Aztek 2003-2005

Bonneville 1996-2005

Firebird / Trans Am 1996-2002

* Some may require part # CP-140.

Grand Am 1996-2000

2003-2005

Grand Prix 2003-2004

Montana 1999-2000

2004-2005

Sunfire 1996-1999

2003-2004

TransSport 1996-1998

Vibe 2004-2005

SATURN

ALL MODELS 1995-1999

SCION

ALL MODELS 2003-2005

* Requires Part # CP-141.

TOYOTA

ALL MODELS 1998-2005

* Vehicle that require Part # CP-141 include 4Runner 2003+, Highlander 2003+, Rav4 2003+, Sienna 2003+, Sequoia 2003+, Tacoma 2003+, and Tundra 2003+. Not compatible with Prius.

VOLKSWAGEN

ALL MODELS 1998-2005