



# 2010-2013 MULTI-MODEL NAVIGATION SD MEMORY CARD


When servicing navigation systems on vehicles equipped with a Secure Digital (SD) memory card, be aware that Mazda currently uses two different SD memory card types:

	SD Card	Year	Model	Note	Image
1	Denso	2010-2012	CX-7 Mazda3	SD memory card map software <u>cannot be updated</u> .	
2	TomTom®	2013	CX-5 CX-9 Mazda3	SD memory card map software <u>can be updated</u> .	

## Denso Navigation SD Memory Card

- Navigation map software update requires an SD memory card replacement.
- Swapping this card into another same model/year vehicle is possible.

## TomTom® Navigation SD Memory Card

- Navigation SD memory card can be flashed with updated map software.
- Swapping this card into another same model/year vehicle is possible if the card has never been updated.
- SD card is locked to the vehicle's navigation unit after an update (cannot be swapped).
- A Secure Digital High Capacity  reader must be used or damage to the SD card may occur.

## Navigation Map Updates (SD card and DVD Systems)

Refer customer to [www.mazdausa.com/navigation](http://www.mazdausa.com/navigation) for navigation map software updates.