

2014 Mazda6, CX-5 TIRE PRESSURE MAINTENANCE MONITOR

Some customers may complain about a TPMS malfunction when they see the "Tire Pressure Increase Pressure" message displayed in the Instrument Cluster Multi-Information Display. This message is a preset service reminder to check the tire air pressures. **It is not a low tire pressure warning or a TPMS malfunction.**



- 4. Set new values (if current values are being reused, skip to the next step)
- 5. Press the INFO button

Turn Tire Pressure Maintenance Monitor OFF

2 zoom-zoom

- 1. Use the steering wheel INFO switch to navigate to the "Maintenance" section of the Multi-Information Display.
- 2. Select "Tire Pressure"
- 3. Select OFF

NOTE: If tire pressure adjustment is necessary, TPMS initialization is also required:

Push and hold the TPMS "SET" switch (left side of dash) until the TPMS warning light () in the instrument cluster flashes twice and a beep sound is heard once.

