
## MULTI-MODEL AUTOMATIC TRANSMISSION OIL PAN BOLTS (UPDATE)

If an automatic transmission oil pan removal is necessary on a transmission listed below, an engineering change has taken place. The automatic transmission oil pan bolts <u>cannot be reused</u>. Install new bolts when installing the oil pan.



- If the control valve body removal is necessary on a FW6A-EL transmission, install a new spring hose clamp when installing the control valve body.
- Workshop Manuals are being revised to reflect these changes.