




HEATER AND AIR CONDITIONER(AUTO)


G-1a



G1-01 A/C AMPLIFIER(I)



G1-02 BLOWER RELAY(HEATER)(F)




FRONT

NOTE: THIS IS THE CONNECTOR AS SEEN FROM THE TERMINAL SIDE.


G1-03 BLOWER MOTOR(I)




G1-06 REFRIGERANT PRESSURE SWITCH(F)



G1-05 AIR INTAKE ACTUATOR(I)



G1-14 INSTRUMENT PANEL(I)-SHORT CORD



TERMINALS OF THIS CONNECTOR ARE INDICATED BY NUMBERS.

HARNESS SYMBOL:  (F)  (E)  (R)

