
8. Perform the 'INSPECTION AFTER TRANSMISSION INSTALLATION', and verify that there is no malfunction.



	1	Shift level knob
	2	Upper panel
ī		