



M-TIPS



2004 RX-8

Rear Doors Won't Fully Open

Some customers may complain the rear doors do not fully open. If the rear doors are not fully opening due to the front seat belt not retracting completely, follow the steps below:

1. Check 15A room fuse. If fuse is okay, proceed to step 2.
2. Check for aftermarket electrical devices that may interfere with room fuse circuit or door switches. If okay, proceed to step 3.
3. Check room fuse circuit, door switches, and front seat belt retractors for proper circuit continuity.