


# RELAY LOCATION

BHE092167730W01



BHE0921W001

1	Trunk lid opener relay
2	AIR pump relay
3	ACC relay
4	Horn relay
5	Front fog light relay
6	Rear fog light relay
7	Drive-by-wire relay
8	Main relay
9	Headlight relay
10	Starter relay
11	Ignition relay
12	TNS relay
13	Cooling fan relay No.3
14	A/C relay

15	Rear window defroster relay
16	Cooling fan relay No.1
17	Seat warmer relay
18	Fuel pump relay
19	Cooling fan relay No.2
20	Blower relay
21	Fuel pump speed control relay