




All Models

Tire Pressure and Tire Rotation Guide

When checking the vehicles tires, the tire pressure specifications for that specific vehicle are located on the drivers door jamb or on the door itself. Use this label to inflate the tires to their proper level based on equipped tire/wheel package specified.



Pages shown are samples from the 2007 CX-9 Owners Manual (Non-Directional Tires)



When rotating tires, always refer to the vehicle's owner manual for vehicle specific rotation procedures. Assuming all models are to be rotated front-to-rear on the same sides may cause uneven/premature tire wear as well as road noise, driveability concerns or decreased tire performance.

Some models require straight front/back rotation while other vehicles require crossing the tires from side-to-side (or a combination of the two). There may also be differences between 2WD and AWD configuration for the same model. Directional tires are always rotated front to rear on the same side.

The vehicle's owners manual shows exactly which tires will be rotated where - for that specific vehicle. Timely rotations, especially the first rotation, are critical to tire life and performance.

From 2008 RX-8 Owners Manual (Directional Tires)

